

TYPICAL TUNING DIAGRAMS





NOTE:

 $\bullet \hspace{0.4cm}$ It is recommended to use the curves as a guide and fine-tune using an SWR-Meter.

Ground Plane Antenna 27-45 MHz



Installation Manual

DESCRIPTION

 $1/4~\lambda$ Ground Plane antenna for base station service working on 27-45 MHz by means of the tuning diagram enclosed. It is entirely made of non-corrosive aluminium and assembled on a strong die-cast base which allows an easy and safe installation assuring very good performances.

SPECIFICATIONS

Electrical Data

Type : $1/4 \lambda$ Ground Plane

Frequency Range : 27-45 MHz tunable by diagram

Impedance : 50 Ω Unbalanced Radiation : Omnidirectional

Polarization : Vertical

Gain : 0 dBd - 2.14 dBi Bandwidth at V.S.W.R. 2:1 : 2.5 MHz at 27 MHz

V.S.W.R. at f. res.:≤ 1.2 : 1Max Power:1000 WattsFeed System / Position:Direct / CenterConnection:UHF Female


Mechanical Data

Materials : Aluminium, Chromed Brass, Nylon, Stainless Steel

Wind Load / Resistance : 126 N at 150 Km/h / 130 Km/h

Wind Surface : 0.11 m²
Height (approx.) : 4730 mm
Weight (approx.) : 1250 gr
Radial Length (approx) : 2680 mm
Mounting Mast : Ø 35-40 mm

TYPICAL S.W.R. RESPONSE



MOUNTING INSTRUCTIONS

